





KIT#: NFS-85942SP006  
Bin#: TBD

<p>F800130 (PM 90492) 5/32 OD x M10 x 1 Push In Elbow - Daimler 12x</p>  <p>King Pins - SpringPin Hangers</p>	<p>E 1/4 5/32 OD Push Lockx 1/4 UNF Elbow Assembly - Daimler 12x</p>  <p>Tie Rods - Drag Links</p>	<p>86433E1 5/32 OD x 1/4-28 UNF Elbow Assembly- Ford 12x</p>  <p>Tie Rods - Drag Links</p>	<p>F801105 (PM 80484-ST) 5/32 OD x 1/4 UNF Straight - Push Lock- Ford 12x</p>  <p>King Pins</p>
<p>327703-3 1/4-28F x 1/4M Elbow - Ford 2x</p>  <p>King Pins</p>	<p>SCE 1/4 5/32 OD Knock-On Elbow Assembly- Ford 2x</p>  <p>Steering Box- Ford</p>	<p>LE 80512-PL 5/32 OD Union - Push Lock 12x</p>  <p>EmergencyLine Repair Ford - Daimler</p>	<p>F800108 (34237-402) Blanking PlugM12 x 1 5x</p>  <p>Pump Repair Ford - Daimler</p>
<p>F800093 (78035-PL) Yellow Injector (0.025cc/stroke) 2x</p>  <p>Pump Repair Ford - Daimler</p>	<p>F800094 (78036-PL) Blue Injector (0.040cc/stroke) 2x</p>  <p>Pump Repair Ford - Daimler</p>	<p>F801251 (PTC-001) Nylon Tube Cutter For Grease Line 1x</p>  <p>Grease Line Repair Ford - Daimler</p>	
<p>F801102 (152823-25) 4mm OD Black Nylon Tubing- Grease Filled 25 FEET</p>			